



COOLIBAH CLASSIC CROSS - WALL TOP ASSEMBLIES⁺

CAROMA

PLUMBERS INSTALLATION INSTRUCTIONS

Installation

- 1) Check that the face of the recess tap body (1) is 0-13mm from the wall/tile face, as shown in Fig.1.
- 2) Check seats in recess tap bodies (1) are in good condition and free of foreign materials. Reseat if required.
Important : All pipework must be thoroughly flushed prior to installation, to remove all foreign matter.
- 3) Remove cap (2) from tap head assembly (3). Fully open tap spindle (4) in tap head assembly (3). Ensure fibre washer and jumper valve are in position as shown.
- 4) Screw tap head assembly (3) into recess tap body (1) by hand and tighten using a suitable tube spanner.
- 5) Screw wall flange (5) over each installed tap head assembly (3), and tighten fully by hand against wall/tile face, taking care not to damage the decorative finish.
- 6) Fit handle assembly as follows:-
 - i) Turn both spindles (4) to the fully closed position.
 - ii) Place retaining nut (7) over spindle (4), with slot facing flange (5).
 - iii) Place retaining clip (8) into groove at bottom of spline in spindle (4).
 - iv) Ensure handle insert (9) is in position in handle (10). Fit handle (10) to spline of spindle, position to suit then push firmly onto spindle until it bottoms internally. Screw retaining nut (7) into handle and tighten with spanner (6) provided.

IMPORTANT
<u>Pressure & Temperature Requirements.</u>
<ul style="list-style-type: none"> • Hot and cold water inlet pressures should be equal. • Static Inlet pressure range : 150 -1000 kPa New Regulation : 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1) • Maximum hot water temperature : 80°C.

