

INSTALLATION INSTRUCTIONS

SEMI INSET COUNTER BASINS

These instructions are for semi inset counter top models designed to be installed partly inset into counter or vanity top.

There are models both with and without a taphole incorporated into the basin.

The counter top (and the basin) must be installed level.

INSTALLATION STEPS

1. Cut out the recess section of the template
2. Fix the template in the desired position with adhesive tape
3. Transfer the cut lines for the basin recess onto the counter top.
4. Cut and remove the section of the benchtop. Check-fit the basin
5. Fit tapware and waste to basin.
6. Position the basin into the cut out recess. Use silicone to seal the basin to the counter top. Smooth sealing joints to an acceptable cosmetic finish

Note: do not use epoxy adhesive to seal the basin.

7. When the silicone has cured connect services to the waste and water supply fittings.

THESE INSTRUCTIONS APPLY TO THE FOLLOWING PRODUCTS:

Model	Description	Nominal Opening Size	
		A	B
JBSG640	Gemelli Round Semi-inset Basin 400Ø	365Ø	
JBSG645	Gemelli Oval Semi-inset Basin 450x410	418	378
JBSG655	Gemelli Rectangular Semi-inset Basin 550x410	520	380
JBSG740	Gemelli Square Semi-inset Basin 400x400	360	360
JBSG745	Gemelli Rectangular Semi-inset Basin 450x410	418	378

TYPICAL PRODUCT ARRANGEMENTS

