

# INSTALLATION INSTRUCTIONS

## INSET VANITY BASINS

These instructions are for inset models designed to be installed inset into a counter or vanity top.

The counter top (and the basin) must be installed level.

### INSTALLATION STEPS

1. Cut out the recess section of the template.
2. Fix the template in the desired position with adhesive tape.
3. Transfer the cut lines for the basin recess onto the counter top.
4. Cut and remove the section of the benchtop. Check-fit the basin.
5. Fit tapware and waste to basin.
6. Position the basin into the cut out recess. Use silicone to seal the basin to the counter top. Smooth sealing joints to an acceptable cosmetic finish.

Note: do not use epoxy adhesive to seal the basin.

7. When the silicone has cured connect services to the waste and water supply fittings.

### TYPICAL PRODUCT TEMPLATE ARRANGEMENT

