



BEFORE YOU START

Please check min max adjustments of your shower screen before commencing installation of base.

The following should be taken into account to determine if the installation method used will be suitable for the screen selected.

Check-in depth	Wall lining thickness
Tiles or Acrylic walls	Front and Return tile flanges

WALLS

Water resistant plaster board installation. The Evo shower base has a 17mm tile flange. Place base against framework, install water resistant plaster board directly on top of tile flange and seal joint with flexible silicone sealant.

Villa board installation. When using villa board the Evo shower base will need to be checked into the framework as shown. Install villa board directly on top of tile flange and seal joint with flexible sealant.

FLOORS

1. Floor boards or sheet flooring must cover the entire underside of the base. Cut hole through floor no greater than 200mm x 200mm (concrete should be 300mm x 300mm). Note: If doing a renovation please check floorboards for soundness as deterioration may have occurred and flooring may need replacing.

2. It is imperative to test for water run off to the waste outlet prior to lining shower walls. This will ensure base is draining correctly. Failure to do so will breach the guarantee.

3. The Evo shower base may be installed on silicone or similar adhesive applied over the entire base area. Lay base on floor and check for level both sides and front & rear. This will allow base to drain effectively as it has inbuilt fall to waste outlet. Note: If your floor is not level a 10mm levelling bed of mortar under the base will ensure your base drains correctly.

4. It is recommended that you cover and protect the base until it comes into service. In case of damage, instructions and repair kit are available from Johnson Suisse P/L.

5. Silicone the bottom edge of the shower wall to the base before the screen is fitted. Silicone is also required around the tap spindles and shower rose outlet.

Cleaning

The surface of this base will resist surface build-up. However, to preserve its high lustre it may be cleaned with a soft cloth using warm soapy water or household detergent. **Avoid All Forms of Abrasive**

If accidental abrasions occur the surface brilliance can be restored by polishing with Marbletrend Ultra Gloss™ or similar silicone-based polish.

Warranty

Refer to www.johnsonsuiss.com.au for warranty terms and conditions

eVO shower base

FOR FURTHER INFORMATION PLEASE CONTACT US:

HEAD OFFICE (SYDNEY)

2/97 Banksia St, Botany, NSW 2019

T 1300 717 717 F 1300 746 480

MELBOURNE

31 Koornang Rd, Scoresby, VIC 3179

T 1300 717 717 F 1800 225 315

BRISBANE

1/477 Newman Rd, Geebung, QLD 4034

T 1300 717 717 F 1300 746 480

PERTH

27 Harris Rd, Malaga, WA 6090

T 1300 717 717 F 1300 746 480

ADELAIDE

Rep: Terry Hayes

T 0499 221 201 F 1800 225 315

HOBART

Rep: Bob Moore

T 0428 223 116 F 1800 225 315

DUBBO

Rogers Agencies

6 Richard Ryan Pl, Dubbo NSW 2830

T 1300 717 717 F 1300 746 480

Email bpa.info@johnsonsuisse.com.au (QLD, NSW, ACT, WA)
bpa.sales@johnsonsuisse.com.au (VIC, SA, TAS)