

Novalink Mk2- with plastic hinge & link plate

- 1 Ensure cistern is mounted at the specified height above pan.
- 2 Cut Flushpipe to dimension shown. Fit Flushpipe to cistern with Kingco Seal and hand tighten coupling nut.
- 3 Check for leaks where shown.
- 4 Mark Link Plate with seat in position before cutting to dimension shown.
- 5 Insert Bolt into Bolt Collar and slide into base of hinge as illustrated in step 1 of Lux Mk2.

NOTE: Once assembled into the Hinge Base the Bolt position can be adjusted backwards, forwards and sideways.

- 6 Place Rubber Pads over Pan Holes flat side down as illustrated in step 2 of Lux Mk2.
- 7 Position Link Plate then slide seat back, locating Link Plate in the hinge block and sliding Bolts through pan holes. Ensure the Rubber Pads locate into the base of the Hinge Assembly.
- 8 Check that the seat is correctly positioned on pan. Slide Wing Nut onto bolt and firmly tighten Nut.

