

Mecca Twin Shower With Air Shower II



43-025 43-0300-025 43-0300-025 43-025 43-025 43-025 43-025 43-025 43-025 43-025 43-025 43-025 43-025

Dimensions are nominal measurements only.







Versions: V1

SPECIFICATION

WELS RATING 3 STAR 9L/MIN

WATERMARK LICENSE WM-060073

TEMPERATURE RATING MIN 1°C-MAX 75°C

PRESSURE RATING MIN 150KPa-MAX 500KPa

AVAILABLE FINISH

CHROME

NR221905hCH

MATTE BLACK

NR221905hMB

BRUSHED NICKEL
NR221905hBN

GUN METAL
NR221905hGM

BRUSHED GOLD NR221905hBG



BRUSHED BRONZE NR221905hBZ

MATTE WHITE
NR221905hMW

MAINTENANCE AND CARE

All surfaces should be cleaned with mild liquid detergent or soap and water.

Do not use cream cleaners or citrus based cleaning products, as they are abrasive.

Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty

PACKING INCLUDES

- 1x hand shower (built-in check valve)
- 1x 1.5m PVC hose
- 1x shower rail
- 1x shower head



Important

All products must be installed by licensed plumbers.

All pipework must be thoroughly flushed prior to installation, as foreign materials may block the flow regulating device and reduce the flow of water.




1.Drill a ϕ 6mm hole at the downwards outlet vertical downward position in the recomendation range.







2. Screw the adapter onto the outlet. Push wall plug into drilled hole. Fit lower mounting pillar in place with screw. Tighten firmly.




3. Screw shower rail into shower arm component. Tighten firmly. Push 2 back plates onto shower arm component and lower mounting pillar.



4. Locate and push shower rail assembly onto wall adaptors. Tighten grub screws firmly with allen key provided.
Slide the back plates against the



5.Screw shower head to shower arm with care. (Note the rubber washer in the shower head.)



6. Please noted the rubber washer in the hand shower.

Connect shower rail and hand shower with hose. TEST & CHECK FOR LEAKS.

wall/tile face properly.