Ceramic Cooktop Touch Control 30cm



Model: CCT3010

- 30cm ceramic cooktop with quartz grey graphics
- Square 'C' shaped edges
- 2 cooking elements, 1800w and 1200w
- Electronic touch controls, nine power levels
- Residual heat indicator
- Child safety lock
- Cooking timer







Arsenic Fre




Child Safety



Spill



Glass Surfac







These dimensions are provided as a general guide only and should not be used for designing or constructing cabinetry or for installation.

To obtain full installation instructions for this appliance go to kleenmaid.com.au and click on User Care Manuals, top right.

Fineline: 0372154 J12625_01

Level 2, 204 Botany Road, Alexandria NSW, 2015 P: 02 9310 1207 • E: support@kleenmaid.com.au www.kleenmaid.com.au

