


Position Shower Rail over Wall Inlet Adaptor and lower Wall Adaptor and gently push in place.


Fasten Shower rail by tightening top and bottom grub screws.




Insert Rubber Washer and Flow Restrictor as shown into Shower Rose.

Screw Shower Rose to arm.

5







Body. Fasten with supplied screw.

Tighten firmly.



adjust to required height.

Tighten with screwdriver.





recommended 150-500

maximum hot water temperature

degrees

NOTE:

- If the pressure exceeds or is likely to exceed 550kpa, an approved pressure limiting device must be

- Flush out all pipe work prior to installation. If the water temperature exceeds 75°C, an
- tempering valve must be fitted. - Installation should comply with Australian standard AS3500.1 or relevant local authority requirements. Showers may not be suitable for use within:
- Gravity-fed water systems

• Pressure supply less than 150kPa; NOTE: The 500kPa maximum water supply pressure does not apply to fire service outlets.

Failure to comply with the above may void all warranties.

WARRANTY:

Please refer to the full warranty statement enclosed with the product before installing. Or

www.phoenixtapware.com.au to download a

MAINTENANCE AND CARE:

- Products should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are
- Use of unsuitable cleaning agents may damage the surface. Any damage caused

in this way will not be covered by warranty.

DISCLAIMER:

While we aim to ensure the specifications shown are correct at the time of printing, Phoenix Tapware reserves the right to make modifications without prior notice. Always use the physical product measurements for mark-ups and roughing-in as the line drawing shown may differ from the actual product over time.

*All measurements are shown in millimeters.

(03) 9780 4200 www.phoenixtapware.com.au