

Code EP34MWS - 34L Microwave Oven



6 AUTO COOKING MENU

The Auto cooking menu, offers 6 pre set cooking functions including pizza, vegetable, beverage, dinner plate, potato and popcorn.

SPEEDY COOKING (30 SECOND QUICK START)

The quick start function enables you to start the unit at 100% power for 30 seconds, at the push of a button. Each press of the start button will increase the cooking time by an extra 30 seconds.

FEATURES

- 34L Capacity
- Digital touch control
- 1100W microwave power
- Auto cooking menus
- Child safety lock
- Grey painted cavity
- Stainless steel front panel finish
- Black outer housing

TIMER

Use to set microwave cooking time. Allows you to set up to 95 minutes.

DEFROST BY TIME

Use to set microwave defrost time. This function will allow you to set a maximum of up to 95 minutes.

DEFROST BY WEIGHT

Defrost food according to weight from 100g to 2kg.

MULTI-STAGE COOKING

This feature allows you to set multiple stages of cooking for example, the defrost function followed by microwave function.

ELECTRICAL REQUIREMENTS

This Microwave is fitted with a cord & 10amp plug.

POWER CONSUMPTION:

- Rated input power (microwave): 1500w
- Rated output power (microwave): 1100w
- Rated input power (grill): 1100w
- Rated Voltage: 220 - 240V

WEIGHT:

20.5kg (Gross) / 18.5kg (Net)

OVEN CAPACITY:

34 Litres

CLEANING AND MAINTENANCE

Simply clean the oven cavity with a slightly damp cloth

PRODUCT DIMENSIONS

Unit dimension with trim (W x H x D): 519x315x407mm

