
# ZIMI


## ZIMI WALL MIXER HANDLE ONLY



# **SPECIFICATIONS**







#### **AVAILABLE IN**



### **INFORMATION**



### MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
- Any damage caused in this way will not be covered by warranty.

Please visit https://www.phoenixtapware.com.au/warranty to view the full warranty

