JBSQ241

Semi-Inset Rectangular washbasin

JohnsonSuisse

380 mm

407 mm

290 mm





Isometric View of the Cut-Out

Cut line of the countertop

Assembly Instructions

1. - Determine the required position of the basin.
   - Fix the template to position with adhesive tape.
   - Transfer the cut line of the basin onto the countertop.
   - Cut the countertop using these lines.
   -
2. - Position the basin in the cutout, and secure to benchtop using suitable silicone.
   - Use at least 2 staples to hold the basin to place
   - Remove any excess silicone.

3. - Once cured, double check alignment of basin.
   - Make all required tapware and drainage connections.

Folding line of the template

Countertop thickness (variable)



	mm
A	410
B	410
C	155
D	800
E	200
F	70
G	120
H	200
J	75
K	355
L	200
M	300

Bathroom Products Australia PL
PO Box 728 Botany, NSW
AUSTRALIA, 1455
T 1300 717 717 | **F** 1300 746 480
E bpa.info@johnsonsuisse.com.au
www.johnsonsuisse.com.au

370 mm