

Care 100

Sanitary Compartment For People with Ambulant Disabilities

4.5/3 litre Toilet Suite





A pedestal type 4.5/3 litre dual flush Care 100 toilet suite installation designed to provide a raised seat height of between 460-480mm for accessible applications &. The versatility of the Care 100 suite makes it ideal for use by both the ambulant people with disabilities and wheel-chair users including wheeled commode chairs.

Important: Reference must be made to AS 1428.1-2009 with current amendments for

people with ambulant disability requirements. The dimensions in this sheet

may change with amendments to the standard.

Pan: Concorde Exposed Trap Care Pan 6 litre full flush washdown type.

S and P-trap unvented only. Slope of P-trap 95°. Traps:

Inlet: 50mm back inlet.

Cistern: Cosmo Care II 4 Star Cistern - A one piece injection moulded tank with a removable

lid. The inlet valve is the Quietflow 2 inlet valve which reduces noise during the filling cycle. Important: Working pressure minimum 30kPa to maximum 1000kPa flow

pressure. Rain water tank compliant.

Round Care Button - Plastic (supplied). Other button options sold separately. See **Buttons:**

section 16.01 for further details.

Inlet and Inlet is in the RH position and is located on the underside of the cistern and is Overflow: interchangeable. Overflow is internal as standard, an external overflow kit is available. Seats: Caravelle Care seat supplied, available in Caroma White (W), Sorrento Blue (SB) and

Anthracite Grey (AG). See Section 15 - SEATS for further details.

Position of Refer to below illustration for specific setout dimensions for this suite to meet

the Pan: projection requirements for people with ambulant disabilities.

Colours:

Installation: The installation of the toilet suite shall be in accordance with the normal minimum

drainline grade requirements in AS/NZS 3500.2.

Dimensions: All dimensions are in millimetres and are subject to normal manufacturing variations.


Caroma pursues a policy of continuing improvement in design and performance of its products. The right is therefore reserved to vary specifications without notice.

635 min. - 660 max

for ambulant installations







All height dimensions to underside of pan, make allowance for mortar bedding.

Mortar bedding: The pan should be fixed to the floor with a sand cement mixture of 3:1 to a depth of 60mm. When bedded the back of the foot of the pan should be approximately 10mm above the finished floor.

Screw fixing: The pan should be bedded with an acetic cured silicone sealant and fixed with corrosion resistant screws and pan guard washers. Use Caroma pan fixing kit. Code No 601150

