

Cosmo Care

Sanitary Facilities - Access and Mobility 4.5/3 litre Dual Flush Toilet Suite





A contemporary designed 4.5/3 litre dual flush Cosmo Care toilet suite installation designed to provide a raised seat height of between 460-480mm for accessible applications &. The pan features a concealed trap which facilitates easy cleaning. The versatility of the Cosmo Care Pan Concealed Trap makes it ideal for use by both the ambulant person with disabilities and wheel-chair users including wheeled commode chairs.

Important: Further reference must be made to AS 1428.1-2009 with current amendments to determine circulation space, grab rail and installation requirements. The dimensions in this sheet may change with amendments to the standard.

Pan: Cosmo Care Pan Concealed Trap pan 4.5 litre full flush washdown type. S trap (WELS 4 star rated) or P trap (WELS 4 star rated). Unvented only. Traps:

Inlet: 50mm back inlet.

Cistern: Cosmo Care II 4 Star Cistern - A one piece injection moulded tank with a removable

lid.The inlet valve is the Quietflow 2 inlet valve which reduces noise during the filling cycle. Important: Working pressure minimum 30kPa to maximum 1000kPa flow pressure. Rain water tank compliant.

Buttons: Round Care Button - Plastic (supplied). Other button options sold separately. See section 16.01 for further details.

Inlet is in the RH position and is located on the underside of the cistern and is interchangeable. Overflow is internal as standard, an external overflow kit is available. Inlet and Overflow: Seats: Caravelle Care seat supplied, available in Caaroma White (W), Sorrento Blue (SB)

and Anthracite Grey (AG). See Section 15 - SEATS for further details. Reference to AS1428.1-2009 must be made in regards to luminance contrast when selecting the

seat colour.

For wheel chair access the installed pan must be a minimum of 800 ± 10 mm from the front of the pan to the finished wall and provide a seat height of 460 to 480mm. The Position of the Pan: projection requirements for people with ambulant disabilities is 610 to 660mm (refer to

page 13.16).

Position of The underside of the cistern must be 600mm minimum from the finished floor. The push the Cistern: button height should be no greater than 1100mm from the finished floor. Colours:

The installation of the toilet suite shall be in accordance with the normal minimum drainline grade requirements in AS/NZS 3500.2. Installation:

Dimensions: All dimensions are in millimetres and are subject to normal manufacturing variations.

Caroma pursues a policy of continuing improvement in design and performance of its products. The right is therefore reserved to vary specifications without notice.

800 ±10mm requirement for

wheel chair access only

128





Note: The projection requirements detailed on this illustration are for wheel chair access only. The projection requirements for people with ambulant disabilities is 610 to 660mm.

All height dimensions to underside of pan, make allowance for mortar bedding.

Mortar bedding: The pan should be fixed to the floor with a sand cement mixture of 3:1 to a depth of 60mm. When bedded the back of the foot of the pan should be

with corrosion resistant screws and pan guard washers. Use Caroma pan fixing kit. Code

* Reference must be made to the AS 1428.1-2009 Amd 1 to confirm installation requirements.

