


INVISICAB®

CONCEALED BATHROOM CABINET


INSTALLATION GUIDELINES



FEATURES


- Two sizes to suit common tile sizes: 300 x 300 mm & 300 x 600 mm
 - Push-to-open, push-to-close mechanism
- Contoured shelf edge ensures water glides away easily
 - Internal polished mirror finish
- 316 marine grade stainless steel body
- 90 mm cabinet depth to suit standard timber framing

TECHNICAL DRAWINGS




IN3030


Suits 300 mm x 300 mm tiles



SIDE




FRONT




IN6030

Suits 600 mm x 300 mm tiles



SIDE





FRONT

IMPORTANT NOTE



InvisiCab® cannot be retrofitted, it must be installed within the wall frame. Please check the product thoroughly for any damages or faults BEFORE installing, as installation of faulty or damaged goods will void warranty.

PLEASE NOTE: FOR BEST RESULTS, SPEAK TO YOUR TILER ABOUT POSITIONING AND TILE THICKNESS BEFORE FITTING THE UNIT.






STEP 1

Use 90 mm deep timber framing to frame the wall. 70 mm deep timber framing can also be used if there is sufficient space behind the frame for a 90 mm cabinet to fit.



STEP 2


Frame out a section based on the size of your InvisiCab®. Approximate cabinet recess dimensions are below. Make sure that there is enough space around the cabinet for gluing and levelling. Check the measurements of the product received to account for manufacturing tolerances.



STEP 3


a. Installation for tiles 10-12 mm thick:

Sheet the wall, making sure that the sheeting is flush with the main body of the cabinet. The angle bar should overlap the sheeting. The cabinet should still be completely removable at this stage. This allows for a flush finish as the tile lip is 14 mm high to allow for 10-12 mm thick tiles.



b. Installation for tiles 6-9mm thick:

For a successful installation with thin tiles, the sheeting should be installed up to the edge of the tile lip and cover the angle bar. This then reduces the height of the tile lip to account for the thin tiles. Complete Steps 4 and 5 before sheeting the wall.




PLEASE NOTE: It is the installer's responsibility to make sure the finished tile level is equal to the top of the tile lip.

STEP 4

Position spacers on the bottom of the frame to assist with levelling in step 5. Add glue/sealant in the recessed area of the timber frame. We suggest using Liquid Nails and Silicone together.

Please note: Spacers and wedges are not supplied with the unit.




STEP 5

Insert the InvisiCab® into the recess, ensuring that the angle bar is at the bottom. The hinges of the cabinet should be on the left-hand side.


Using a spirit level and wedges, adjust the position of the InvisiCab® until it is level both horizontally and vertically.

Allow for the glue/sealant to dry as per the instruction on the tube.




STEP 6

Fill in the gaps around the outside edges of the cabinet or protruding tile lip with silicone to ensure an adequate seal. Wipe away excess silicone with cloth.




STEP 7

Waterproof the wall, leaving the tile lip exposed. If the angle bar is still exposed (10-12 mm tile installation), then it can be covered at this stage.




STEP 8

Apply tiling around outside edge of the tile lip and inside the door of the InvisiCab®.



STEP 9

Check that the door is aligned correctly, and if necessary, adjust the hinges as per the diagram below.



HOW TO CLEAN YOUR INVISICAB®

InvisiCab® features an internal polished mirror finish that is susceptible to scratches if not cared for properly. Fienza recommends using a non-abrasive, specially formulated stainless steel cleaner to ensure a smooth, streak and scratch-free finish. Do not use citrus-based cleaners or metal scourers on this product.

Please note: Some residue may remain once the protective film is removed from the polished inner surface. Please follow the instructions above for safe cleaning.

WARRANTY

Incorrect installation, or installation of faulty or damaged goods, will void warranty. Please check product thoroughly for any damages or faults BEFORE installation and follow the installation guidelines carefully.

Warranties

| | |
|--------|--------------------------------------|
| 7 Year | Replacement cabinet |
| 1 Year | Replacement door hinges & components |

Finishes: External finish is not covered under warranty as it is not visible after installation. Minor scratches to internal finishes are not covered under warranty. No warranty claims on finish will be offered after the installation.

HOW TO CLAIM YOUR WARRANTY

Congratulations on purchasing your InvisiCab®. We believe in what we sell and make sure our warranty periods extend beyond what the Australian Consumer Law requires. Please read below guide information pertaining to your warranty.

Important Information

- Proof of Purchase is necessary to claim.
- The warranty only applies to the original owner and is not transferable.
- Product must be installed by a licensed tradesman. Failure to do so voids warranty.
- Product must be installed according to manufacturer's instructions. Failure to do so voids warranty.

How do I claim warranty?

Contact the store from which the product was purchased. Or, if for some reason you cannot get into contact with the store you may contact Fienza on (07) 3490 6700. Please note you may be asked for both your invoice from the store and the invoice from your licensed installer.

What will Fienza do to fix a problem?

This will depend on the problem with the product. Fienza will do one of the following:

- Replace the faulty product.
- Arrange a licensed service agent to repair or replace the product.
- Arrange a Refund with the store from which you purchased the product (only in the case of major failure and within the warranty period). Please note in order to receive a refund, the product (with Major Failure) needs to be returned to either Fienza or the store where the product was purchased.

Exclusions

To the fullest extent permitted by law, Fienza excludes all liability for damage or injury to any person, damage to any property, and any indirect consequential or other loss or damage. Fienza will not be liable to bear the expense of claiming the warranty (i.e. time off work, postage, etc).

Australian Consumer Law Guarantee

The benefits given by these warranties are in addition to the other rights and remedies that consumers may have under the Australian Consumer Law and any other applicable laws. Our goods come with guarantees that cannot be excluded in the Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.