

## Important Information

## INSTALLATION INSTRUCTIONS

\* Single & Double towel rail tubes can be cut short to suit different stud spacings, if required, follow disassembly & reassembly step D below.

\* Distance between centres of mounting bracket (3) with holes:

- For 840mm Single Towel Rail:  $800 \pm 1\text{mm}$
- For 840mm Double Towel Rail:  $800 \pm 1\text{mm}$
- For 640mm Single Towel Rail:  $600 \pm 1\text{mm}$
- For 640mm Double Towel Rail:  $600 \pm 1\text{mm}$
- For Metal Shelf:  $450 \pm 1\text{mm}$
- For Hand Towel Rail:  $250 \pm 1\text{mm}$

\* To prevent drill from wandering on tiled surface it is recommended that masking tape be applied before drilling.

\* Do not use accessories for personal support.

\* Over time, the mounting screw which is used to install the product may be affected by exposure to water/moisture, this may cause the screw to rust and loosen. You should periodically check that your accessories are fastened securely to the wall.

### Installation

#### A) TOWEL RAIL LENGTH MODIFICATION (Fig. 3):

- 1) Remove retaining screws (7) from mount post (8) with Allen key (2).
- 2) Pull the rail tube (9) out of mounting posts (8).
- 3) Protect the rail to prevent damage. Cut towel rail tube(s) (9) from one end to suitable length, remove burrs on the cut ends.
- 4) Refit towel rails tube(s) (9) into mount post (8) and tighten screws (7) using Allen key (2).
- 5) Proceed with towel rail accessories installation as described below

#### B) DETERMINE POSITION:

- 1) Position accessories in a desired location against wall or fixing surface. Align mounting post with stud or noggin where applicable. Mark the screw hole positions from the mounting bracket (3) onto the wall.
- 2) Loosen grub screw (1) with Allen key (2) to remove mounting bracket (3).

#### C) DETERMINE WALL TYPE:

**Solid Walls:** - (Brick, masonry blocks, concrete etc)

- 1) Drill holes 6mm diameter, 40mm deep for wall plugs (4).
- 2) Insert rounded end of the wall plugs (4) into the drilled holes and press in until flush with the wall surface.
- 3) Align screw holes in mounting bracket (3) with wall plugs, pass the screws (5) through holes in mounting bracket (3) before inserting into the wall plugs (4) and tighten screws (5).

**Untiled Plasterboard cavity walls (on timber noggin or stud) :-**

- 1) Determine a suitable position to attach the mounting bracket (3) so that it can be fixed to a stud or noggin in the wall.
- 2) Drill  $\varnothing 3.2\text{mm}$  holes at the marked positions, align the fixing slots/holes on mounting bracket (3) with the holes on the wall. Fix using screws (5) through the mounting bracket (3) and timber stud or noggin.

**Untiled Plasterboard cavity walls (hollow) :-**

Suitable hollow wall anchors (not supplied) must be used. Drilled hole size is dependant on the type and size of wall anchor used. Follow install instructions supplied with the cavity anchor.

#### D) INSTALLATION:

- 1) Slide the cover plate (6) over the mounting bracket (3).
- 2) Slide mounting post of accessory onto mounting bracket (3) and hold it in position.
- 3) Tighten grub screw (1) until wall cover plate (6) sits firmly against the wall.




Fig. 1




Fig. 2




Fig. 3




Fig. 4

Fig. 5