

PLUMBERS INSTALLATION INSTRUCTIONS


Important Information

- * **Generic installation for wall and ceiling mounted shower arms that are sold separately.**
- * **All pipework must be thoroughly flushed prior to installation.**


IMPORTANT
<u>Pressure & Temperature Requirements.</u>
<ul style="list-style-type: none"> • Hot and cold water inlet pressures should be equal. • Inlet pressure range : 150 -1000 kPa New Regulation:- 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1) • Maximum hot water temperature : 80°C.

Installation

- 1) Check that threaded nipple (1) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread.
Important : Care must be taken that thread tape cannot become dislodged and block the flow regulating device, causing a reduction in water flow.
- 2) Slide the cover plate (3) together with the 'O'Rings over the arm (2) as shown. Carefully screw the arm (2) onto the threaded nipple (1) until the threaded end is adjacent to the wall/tile or ceiling face and the connection thread (4) is pointing down as shown, taking care not to damage the decorative finish. **DO NOT OVERTIGHTEN.** Push the cover plate (3) along the arm (2) until it contacts the wall/tile or ceiling face.
- 3) When installing the shower head (5) onto the connection thread (4) of the shower arm (2), refer to the individual instructions supplied with the shower head.



TYPICAL WALL ARM INSTALLATION



TYPICAL CEILING ARM INSTALLATION