


PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * Generic installation for wall and ceiling mounted shower arms that are sold separately.
- * All pipework must be thoroughly flushed prior to installation.
- * Where showers incorporate flow controllers, care must be taken during installation to ensure that the male connecting threads do not damage flow controllers.

Installation

- 1) Check that threaded nipple (1) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread.
Important : Care must be taken that thread tape cannot become dislodged and block the flow regulating device (when fitted), causing a reduction in water flow.
- 2) Slide the cover plate (2) onto the larger diameter of the shower arm (3) then screw the shower arm (3) onto the threaded nipple (1) and position as required. **DO NOT OVERTIGHTEN**. Push the cover plate (2) against the wall/ceiling face.
- 3) When installing the shower head (5) onto the connection thread (4) of the shower arm (3), refer to the individual instructions supplied with the shower head.



IMPORTANT

Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Inlet pressure range : 150 -1000 kPa
New Regulation:- 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
- Maximum hot water temperature : 80°C.

