

BATH/SHOWER MIXER WITH DIVERTER - IN WALL BODY KIT

+

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * Brazed connections should NOT be made directly onto the mixer, as excessive heat will cause permanent damage.
- * All pipework must be thoroughly flushed prior to installation.

Installation (Fig. 1)

- 1) Fit mixer body (1) onto a suitable mounting plate or noggin in the wall and secure using screws (not supplied) through the holes in its base. When facing the mixer, the connections should be as follows:

Hot water inlet connection 'H' to the left.
Cold water inlet connection 'C' to the right.
Mixed water outlet connection, vertically upwards.
Check all connections for leaks.

Important :

- * The front face of the mounting plate or noggin must be parallel to the finished wall/tile face.
- * To avoid damaging the decorative finish, do not remove the protective sleeves (2) & (3) until installing the trim kit.
- * The rotational alignment of the body must be accurate and may be essential if the cover plate has flat sides. (Refer to the trim kit instructions)




Fig. 1

IMPORTANT

Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Static inlet pressure range : 150 -1000 kPa
New Regulation :-500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
- Maximum hot water temperature : 80°C.

+