

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

* All pipework must be thoroughly flushed prior to installation.

Installation

1) Check that threaded nipple (1) is the correct length, as shown. Apply thread tape to the thread. Ensure 'O' Ring (8) is in position in groove of wall base (2).

Hint: Apply a light smear of a suitable grease to the 'O' Ring (8) to help retain it in the groove in the wall base (2).

Screw the wall base (2) onto the threaded nipple (1), using a 6mm allen key (4⁺), until 'O' Ring (8) has contacted the wall/tile face & the **caroma** marking is at the top.

DO NOT OVERTIGHTEN.

Apply suitable lubricant to 'O' Rings (3) on wall base (2).

2) Fit wall bath outlet (5) onto spigot of wall base (2), then push it firmly against the wall base while tightening grub screws (6) using the 2.00mm allen key (7) provided. Take care that the top face of the bath outlet is horizontal before tightening screws (6).

IMPORTANT
<u>Pressure & Temperature Requirements.</u>
• Hot and cold water inlet pressures should be equal.
• Static Inlet pressure range : 150 - 1000 kPa New Regulation :- 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1- 2003, Clause 3.3.4)
• Maximum hot water temperature : 80°C.

+ Not supplied.




Fig. 1